

inicio:

if pinc.0=0 then desligado 'Botão de confirmação

if pinc.0=1 then verifica

goto inicio

desligado:

low b.0 'desliga led 1

low b.1 'desliga led 2

low b.2 'desliga led 3

low b.3 'desliga led 4

low b.4' boneco

low b.5 'boneco

low b.6 'fala PARABENS ACERTASTE

low b.7 'fala TENTA OUTRA VEZ

goto inicio

verifica:

if pinc.4=1 and pinc.5=1 and pinc.6=1 and pinc.7=1 then tudo\_certo 'REEDS

if pinc.4=0 and pinc.5=0 and pinc.6=0 and pinc.7=0 then tudo\_errado

if pinc.4=1 and pinc.5=0 and pinc.6=0 and pinc.7=0 then janela\_1\_certo

if pinc.4=0 and pinc.5=1 and pinc.6=0 and pinc.7=0 then janela\_2\_certo

if pinc.4=0 and pinc.5=0 and pinc.6=1 and pinc.7=0 then janela\_3\_certo

if pinc.4=0 and pinc.5=0 and pinc.6=0 and pinc.7=1 then janela\_4\_certo

if pinc.4=1 and pinc.5=1 and pinc.6=0 and pinc.7=0 then janela\_1\_2\_certo

if pinc.4=0 and pinc.5=0 and pinc.6=1 and pinc.7=1 then janela\_3\_4\_certo

if pinc.4=1 and pinc.5=0 and pinc.6=1 and pinc.7=0 then janela\_1\_3\_certo

if pinc.4=0 and pinc.5=1 and pinc.6=0 and pinc.7=1 then janela\_2\_4\_certo

if pinc.4=1 and pinc.5=0 and pinc.6=0 and pinc.7=1 then janela\_1\_4\_certo

if pinc.4=0 and pinc.5=1 and pinc.6=1 and pinc.7=0 then janela\_2\_3\_certo

if pinc.4=1 and pinc.5=1 and pinc.6=1 and pinc.7=0 then janela\_1\_2\_3\_certo

if pinc.4=0 and pinc.5=1 and pinc.6=2 and pinc.7=1 then janela\_2\_3\_4\_certo

if pinc.4=1 and pinc.5=1 and pinc.6=0 and pinc.7=1 then janela\_1\_2\_4\_certo

if pinc.4=1 and pinc.5=0 and pinc.6=1 and pinc.7=1 then janela\_1\_3\_4\_certo

goto inicio

tudo\_certo:

high b.0 'led 1

high b.1 'led 2

high b.2 'led 3

high b.3 'led 4

pause 500

low b.4 'liga boneco DANÇA

high b.5 'liga boneco DANÇA

high b.6 'fala PARABENS ACERTASTE

low b.7 'para de falar tenta outra vez

pause 6000 'TEMPO DO ACERTASTE

goto inicio

'XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX

tudo\_errado:

low b.0 'desliga led 1

low b.1 'desliga led 2

low b.2 'desliga led 3

low b.3 'desliga led 4

low b.4

low b.5 '

low b.6 '

high b.7 'fala TENTA OUTRA VEZ

pause 3000 'TEMPO DO ERRASTE

goto inicio

janela\_1\_certo:

high b.0 'led 1

low b.1 'desliga led 2

low b.2 'desliga led 3

low b.3 'desliga led 4

pause 500

low b.4

low b.5 '

low b.6 '

high b.7 'fala TENTA OUTRA VEZ

pause 3000

goto inicio

janela\_2\_certo:

low b.0

high b.1

low b.2

low b.3

pause 500

low b.4 'motor do boneco

low b.5

low b.6

high b.7 'fala TENTA OUTRA VEZ

pause 3000

goto inicio

janela\_3\_certo:

low b.0

low b.1

high b.2

low b.3

pause 500

low b.4

low b.5 '

low b.6 '

high b.7 'fala TENTA OUTRA VEZ

pause 3000

goto inicio

janela\_4\_certo:

low b.0

low b.1

low b.2

high b.3

pause 500

low b.4

low b.5 '

low b.6 '

high b.7 'fala TENTA OUTRA VEZ

pause 3000

goto inicio

janela\_1\_2\_certo:

high b.0

high b.1

low b.2

low b.3

pause 500

low b.4

low b.5 '

low b.6 '

high b.7 'fala TENTA OUTRA VEZ

pause 3000

goto inicio

janela\_3\_4\_certo:

low b.0

low b.1

high b.2

high b.3

pause 500

low b.4

low b.5 '

low b.6 '

high b.7 'fala TENTA OUTRA VEZ

pause 3000

goto inicio

janela\_1\_3\_certo:

high b.0

low b.1

high b.2

low b.3

pause 500

low b.4

low b.5 '

low b.6 '

high b.7 'fala TENTA OUTRA VEZ

pause 3000

goto inicio

janela\_2\_4\_certo:

low b.0

high b.1

low b.2

high b.3

pause 500

low b.4

low b.5 '

low b.6 '

high b.7 'fala TENTA OUTRA VEZ

pause 3000

goto inicio

janela\_1\_4\_certo:

high b.0

low b.1

low b.2

high b.3

pause 500

low b.4

low b.5 '

low b.6 '

high b.7 'fala TENTA OUTRA VEZ

pause 3000

goto inicio

janela\_2\_3\_certo:

low b.0

high b.1

high b.2

low b.3

pause 500

low b.4

low b.5 '

low b.6 '

high b.7 'fala TENTA OUTRA VEZ

pause 3000

goto inicio

janela\_1\_2\_3\_certo:

high b.0

high b.1

high b.2

low b.3

pause 500

low b.4

low b.5 '

low b.6 '

high b.7 'fala TENTA OUTRA VEZ

pause 3000

goto inicio

janela\_2\_3\_4\_certo:

low b.0

high b.1

high b.2

high b.3

pause 500

low b.4

low b.5 '



low b.6 '

high b.7 'fala TENTA OUTRA VEZ

pause 3000

goto inicio

janela\_1\_2\_4\_certo:

high b.0

high b.1

low b.2

high b.3

pause 500

low b.4

low b.5 '

low b.6 '

high b.7 'fala TENTA OUTRA VEZ

pause 3000

goto inicio

janela\_1\_3\_4\_certo:

high b.0

low b.1

high b.2

high b.3

pause 500

low b.4

low b.5 '

low b.6 '

high b.7 'fala TENTA OUTRA VEZ

pause 3000

goto inicio

